



304 Lenoir Drive
Winchester, VA 22603
Phone: (540) 722-2017
Fax: (540) 722-2018

Hey Cowboy:

To install a cover, just pull it over the butt stock like a sock then worry the seam down and around the butt plate with your thumbs and palms to get it straight and even on the butt plate. Continue stitching the main seam, one hole pair at a time, starting on the same side each time, keeping the seam straight. Pull the stitches up tight with each pair.* When you get about 2" from the end, lay a loop of extra sinew under the seam with the knotted end sticking out between stitches and the loop past the end of the cover. Continue stitching to the end. When it is stitched up tight, tie off ends with a square knot.** LEAVE ABOUT 2" OF ENDS when you cut 'em!! Stick the ends through the loop and pull them back under the seam with the loop.

* Works best to pull straight out from the holes rather than across.

** I like to bring the sinew back across after the last holes and go back through those holes from the tope to the under side and then ties the knot.

You should now have a butt cover to be proud of!